

# Release Note Auto Dialer 1.0.5, Edition 1

THIS DOCUMENT CONTAINS CONFIDENTIAL AND PROPRIETARY INFORMATION OWNED BY EPYGI TECHNOLOGIES LTD. ANY COPYING, USE OR DISCLOSURE OF THE DOCUMENT OR THE INFORMATION CONTAINED HEREIN WITHOUT THE WRITTEN PERMISSION OF EPYGI TECHNOLOGIES LTD. IS STRICTLY PROHIBITED.

THIS DOCUMENT IS PROVIDED TO YOU FOR INFORMATIONAL PURPOSES ONLY. The information furnished in this document, believed by Epygi Technologies to be accurate as of the date of publication, is subject to change without notice. Epygi Technologies assumes no responsibility for any errors or omissions in this document and shall have no obligation to you as a result of having made this document available to you or based upon the information it contains.

Epygi is a registered trademark of Epygi Technologies, Ltd. All other products and services are the registered trademarks of their respective holders

## 1 Introduction

---

This Release Note describes hardware and software requirements to use with the

**Epygi Auto Dialer software 1.0.5 Date: May 31, 2011**

Additional enhancements, bug fixes and known issues incorporated in this software will be listed as known.

Date: June 16, 2011

## 2 Requirements

---

The Epygi Auto Dialer is a licensable feature that enables Epygi IP PBXs to perform immediate or scheduled dialing to phone numbers from a calling list, with the option of playing one or more voice files and a voice menu.

The Auto Dialer can prompt the called party to enter a response by pressing one or more DTMF keys to navigate options. The responses entered are then updated in the calling list.

The feature is implemented as a MS Windows™ application.

The calling list that is used and updated by the Auto Dialer can be uploaded from a list of names and contact numbers that are stored in an MS Excel™ file. The contact numbers can also be manually entered from within the Auto Dialer's calling list screen.

**Please Note:** Auto Dialer does not require the additional 3pcc license to be installed on the Epygi IP PBX.

There is no limitation on the number of Auto Dialers that can be connected to the same IP PBX unit. The only limitation is there is a maximum number of concurrent calls originated by all connected Auto Dialers; it cannot exceed the total number specified in the Auto Dialer feature keys installed on the IP PBX unit.

### 2.1 System Requirements

The following specifications are required for the proper operation of the Epygi Auto Dialer:

- Min required space on PC – 8 MB
- MS Windows XP, MS Windows 7, MS Windows Vista. MS Windows servers 2003 and 2008
- Microsoft .NET Framework 3.5
- Network connection to the Quadro IP PBX

#### Network Connectivity

- The Quadro IP PBX and the host where the Auto Dialer is running should be visible to each other.

### 2.2 Quadro Software Requirements

The Epygi Auto Dialer application is compatible with the following Quadro IP PBXs beginning with the software versions listed below:

- Quadro2x: SW-5.2.46
- QuadroM32x: SW-5.2.46
- QuadroM8L/M26x/M26xi/M12Li: SW-5.2.46

## 3 New Features History

---

No new features here at the moment.

## 4 Changed Features History

---

No changed features here at the moment.

## 5 Fixed Issues

---

No fixed issues here at the moment.

## 6 Known Issues

---

D: Description

C: Consequences

Fix: How to avoid the situation, or what to do in case the situation has occurred.

<b>Auto Dialer doesn't ask for confirmation when the user wants to close the program using File-Exit menu</b>		<b>17013</b>
D:		
C:		
Fix:	Will be fixed in the next releases.	

## 7 Installing and Upgrading Instructions

---

Before installing Epygi Auto Dialer, go to the **System -> Features** on the Quadro GUI to make sure the Auto Dialer Support feature is activated.

**Please Note:** Auto Dialer does not require the additional 3pcc license to be installed on the Epygi IP PBX.

To install, run the setup files for Auto Dialer and follow the instructions of the setup wizards until the end. For information on how to activate and configure the Auto Dialer feature on the Quadro IP PBX, see the Administrator's Manual for the Quadro.

To upgrade from an existing version, close the Auto Dialer and run the setup wizard for the new version. The configuration and the data will remain after the upgrade. It is not necessary to uninstall the previous version before performing the upgrade.